STEP BY STEP GUIDE

STEP 1: Connect the two curved tubes together to form an oval base (A).

STEP 2: Connect two pairs of Vertical tubes (B) together to form two long vertical poles.

STEP 3: Using a T-Clip (C), connect each long vertical poles to each side of the oval base. Note the two marks on each side of the oval base.

T-Clips should be positionned onto the marks, then well tightened.

STEP 4: With the unit facing you, position a Left T-Clip with one spring (D) towards the far bottom of the left long vertical pole.

Note: the spring of the Left T-Clip should be facing up, while its plastic nut should be facing back.

Insert a horizontal tube (F) into the Left T-Clip.

Keep the T-Clip loose, do not tighten it yet.

STEP 5: Repeat on the other side, by positionning a Right T-Clip with one spring (E) towards the far bottom of the right long vertical pole.

Connect that T-Clip with the other end of the horizontal tube, then tighten both the Left and Right T-Clips well.

STEP 6: Pick the remaining horizontal tube with pre-installed corners.

Connect it to the top of the unit, by simply inserting the corners into the tubes.

POSTER INSTALLATION

Before inserting a poster, first open the mobile flap on each of the four poster clips, as shown to the right.

IMPORTANT: The flaps must be open to a full 90°, in order to allow enough space for the poster insertion.

Starting with a top corner of the unit, <u>fully insert</u> a first poster corner into a poster clip.

Secure the poster corner in place by <u>pushing down all</u> the way onto the flap.

Now, repeat and proceed with the <u>corner beside it</u>, as illustrated to the right.

You may now attach both remaining corners, in no particular order.







FLEX FLOOR STAND WITH OVAL BASE



